

## VEHICLE APPLICATION

---

### Step 1a: Clean the surface

Remove dirt, dust, oils, stains, and any other contaminants from the surface. Use a wax-free soap to wash the surface, preferably one that will also remove old wax or other products on the surface, we recommend Dawn soap to strip the surface.

### Step 1b: (Optional): Clay/polish surface

Clay the vehicles paint to remove further contaminants that may not have been removed from washing. Polishing the surface will remove unwanted swirls and scratches. The more decontamination and prep of paint will lead to a more effective and longer lasting coating.

### Step 2: Wash and dry

Remove any polish that may be left from the previous step by washing the surface with Dawn soap. This ensures the surface is stripped and clean. Dry the surface and let air dry to ensure no water is on the surface. The surface is now ready for application.

### Step 3: Application

**DO NOT APPLY IN DIRECT SUN. COATING WILL BE VERY DIFFICULT TO LEVEL OUT.**

Apply 8-10 drops of Ceramlock 700 to a smooth or microfiber textured applicator pad. Apply to the surface and work the product in a circular or cross pattern motion to ensure coverage while filling pores. Apply product to the applicator often to keep the applicator wet.

Let the product bond to the surface with the following times:

Bond time: Minimum 5-10 minutes in most applications. Quicker dry time in warmer, humid environments. (May take up to 10-15 minutes in colder environments)

Remove solvent residue by lightly wiping the product in a circular motion with a clean microfiber cloth. This should be a very quick wipe of the surface. Do not over buff as this would start to remove the coating. Glass may take a bit more buffing to get the desired finish.

## CERAMLOCK 700 CERAMIC COATING

### *Application*

Once the solvent is removed, the clear, slick, glossy, coating will be left behind bonded to the surface. The coating will continue to cure and increase bond strength for 4-5 days until maximum durability and protection is reached.

**Avoid water for 24 hours. Wait at least 2 hours before driving. Do not wash for 7 days.**

**Our 600 EZ-Slick™ is fully compatible with our 700 series for a quick enhancement of hydrophobic and slick properties.**