

EZ-Slick 700

Vessel Application Instructions



Proper application is essential to maximize durability, shine, and performance. This guide will walk you through the step-by-step process to ensure a professional-grade result.

MADE IN USA

APPLICATION MATERIALS

- EZ-Slick 700 Coating
- Applicator pad
- Isopropyl alcohol
- Edgeless Microfiber towel
- Gloves

Please note:

Disclaimer: All surfaces must be thoroughly free of oxidation before application. Use proper sanding, compounding, and polishing steps.. The coating will not remove or hide imperfections—any oxidation, scratches, or dull areas should be corrected beforehand. For optimal performance, surfaces should be **smooth and glossy** prior to coating. Proper surface preparation will ensure optimal gloss, durability, and protection.

Surface Preparation:

Wash with a degreasing soap, such as Dawn to remove any compound or polish from previous steps, then dry the surface completely.

A final prep wipe with isopropyl alcohol may be used as well.

APPLICATION

SURFACES ARE CLEAN, FREE OF WAXES, AND DRY

Avoid intense sun contact. Do not apply to hot surfaces.

Product Preparation:

- Lightly swirl the EZ-Slick 700 bottle to mix.

Gelcoat/Paint/Glass/Metal Application Process:

- Moisten the applicator with Ceramlock 700, including edges of the pad.
- With the pad flat on the surface, apply to the surface in side by side cross motion, or in a circular motion. Apply more drops of product to pad every few feet of surface. The coating should have a wet look when applying.
- Allow the coating to set up for **5-10 minutes** before wiping. The coating will develop a slight haze, but not necessarily a rainbow effect.
- **Buffing:** Use a new, high quality, edgeless microfiber towel to ensure no scratching when removing solvents. Gently wipe off excess coating to reveal a smooth, glossy finish. The slight haze look will easily wipe away, no excess buffing required.
- A second coating may be applied at any time, one coat is usually enough to seal the surface.

Upholstery:

- With the applicator moistened, simply wipe a light coat onto surfaces. Lightly wipe with a microfiber towel to eliminate any streaks if necessary.. Don't buff.

Note: Not recommended for damaged or faded fabric. This product will protect fabrics, not restore them.

Curing and Finalizing:

- Coating is dry to touch in 1-2 hours.
- Avoid exposure to water for 2 days.
- Full cure in 5 days.

Aftercare:

Do not wax. Wash with marine soap of your choice. Avoid harsh chemicals.

Use soft brushes and microfiber towels when washing. Dry with high quality towels or chamois (shammy).

For maximum longevity, wash your coated surface every 1-2 weeks, or keep covered.

SUPPORT

Contact us with any questions or concerns!

www.ceramlockcoatings.com

team@ceramlockcoatings.com

DISCLAIMER: Results may vary based on application methods, surface preparation, and environmental conditions. Refer to SDS for full handling and safety precautions. Ceramlock Coatings Inc, is not liable for misuse or unintended results. Test on a small area before full application.